

p-port fitting for Apeks XTX 2nd stage.



The set contains the following parts



2x o-rings (both are same size)

1x clip/distance plate

1x the p-port fitting itself, with two set screws

how to mount it:



put the slightly greased o-rings to this position.



then put the distance plate between the two o-rings. please take care this plate is asymmetric (as you see in the picture)and you put it on in the correct position.

It is cutted on the lower side and the two holes for the set screws are NOT in the middle!



Please place the clip as see in the following pics





the holes have to be to the front!



take care the set screws are out, so they are not staying inside!





Now put the adapter on, take care: it is stiff fitting! The first o-ring is the one sealing, the second is for adjusting the set only, it does not seal.

put it on like seen here



Then softly tight the set screw, please SOFTLY tight them, normal position if the set screw is, It is enough when head of screw is aprox 1-2 mm inside the adapter.